



INSTRUCTIONS FOR KIT NO. SP66252

Units equipped with metal shroud:

Discard metal shroud (35844) and 4 washers (35234). Place rubber shroud (66250) on unit, add plate (65863), and 4 screws.

Units equipped with rubber shroud (65285) and 4 spacers (65286):

Discard rubber shroud, 4 spacers, and plate (35847). Place rubber shroud (66250) on unit, add plate (65863—1/8" thick), and 4 screws.

**SIoux
TOOLS INC.**

250 SNAP-ON DRIVE ■ PO BOX 1596 ■ MURPHY, NC 28906 ■ USA ■

Printed In U.S.A.

This pdf incorporates the following model numbers:

SP66252