

- OILING INSTRUCTIONS -

Due to the high speed of the right angle gear set, lubrication instructions must be followed in order to achieve long gear life.

This tool provides optimum gear life when used with an inline oiler. Set the oiler to deliver 2-3 drops per minute. Manual oiling of the tool at intervals will degrade gear life.

Refer to lubrication instructions shipped with the tool.



2901 FLOYD BOULEVARD ■ PO BOX 507 ■ SIOUX CITY, IOWA 51102-0507 USA ■

Form No. A759

This pdf incorporates the following model numbers:

1964

1965

1965-5/8

1966

1967

1968

AG1963