



# SERIAL CODE EXPLANATION CHART

Explanation of code is shown using the following example of Serial "M M L B".

	<b>M</b>	<b>M</b>	<b>L</b>	<b>B</b>	
	/	/	/	/	
<b>ASSEMBLY LOCATION</b>		<b>YEAR</b>	<b>MONTH</b>		<b>SERIAL</b>
M—MURPHY, NC		1994—A	JANUARY—A		Consecutive letters assigned for each serial Break starting with "A"
S—SIOUX CITY, IA		1995—B	FEBRUARY—B		
L—LEMARS, IA		1996—C	MARCH—C		
V—VERMILLION, SD		1997—D	APRIL—D		
P—OTHER LOCATIONS		1998—E	MAY—E		
		1999—F	JUNE—F		
		2000—H	JULY—H		
		2001—K	AUGUST—K		
		2002—L	SEPTEMBER—L		
		2003—M	OCTOBER—M		
		2004—N	NOVEMBER—N		
		2005—P	DECEMBER—P		
		2006—R			
		2007—S			
		2008—T			
		2009—U			
		2010—V			
		2011—W			
		2012—X			
		2013—Y			
		2014—Z			

Serial "M M L B" would read, assembled at Murphy, NC in 2003 during September and was Serial "B" version of the tool at time of assembly.

