



NOTE: Parts are no longer available for this tool.

The manual will continue on the next page.

SIoux**TOOLS**

**Parts List for No's. 475, 476, 477
AIR IMPACT WRENCH and
No. 472 & 472B SCREW DRIVER**

(UP TO SERIAL B99)

Furnish Catalog and Serial Number When Ordering Parts

Fig- ure	Part No.	Name	Fig- ure	Part No.	Name
1	14360	Protector—Rubber (472-475)	40	44100	Bushing—Reducing
	14364	Protector—Rubber (476-472B-477)	41	21417	Spring
2	33976	Ass'm.—Hammer Case	42	33993	Screen—Air
3	07091	Screw—#10 (4)	43	30359	Plug—Pipe
4	09726	Washer—Lock #10 (8)	44	30325	Pin—Groove (2)
5	35062	Bail—Front	45	21401	Spring—Throttle Valve
* 6	14339	Ring—"O"	46	06362	Screw—#6
7	35073	Washer—Split (Set of 2) (Up to Serial 16000)	47	35082	Deflecor—Air
	30617	Ring—Spring Retainer (Serial 16001 & Up)	*48	14325	Valve—Rubber
8	35081	Washer (Up to Serial 16000)	49	25957	Washer
	44882	Retainer—Ring (Serial 16001 & Up)	50	33892	Ass'm.—Valve
9	21410	Spring—Hammer	51	33928	Ass'm.—Valve Seat
10	11531	Hammer—Auxiliary	52	33881	Trigger
11	10322	Ball	53	14047	Pin—Lock (Up to Serial 7000)
12	10234	Bearing—Ball (Up to Serial 7000)	54	44209	Cam—Spindle (472-475) (Up to Serial 16000)
	44482	Bearing—Steel (Serial 7001 & up)	44907	Cam—Spindle (472-475) (Serial 16001 & Up)	
13	44234	Frame—Hammer	44249	Cam—Spindle (476-477-472B) (Up to Serial 16000)	
14	10236	Bearing—Ball	44906	Cam—Spindle (476-477-472B) (Serial 16001 & Up)	
† 15	43885	Housing	58	33985	Ass'm.—Socket Retainer (475-476)
16	10247	Bearing—Ball	33986	Ass'm.—Socket Retainer (477)	
17	33975	Plate—Front End	59	33977	Ass'm.—Anvil (475-476)
* 18	43027	Vane—Rotor (Set of 5)	43010	Ass'm.—Sp. 3" Longer Anvil (475-476)	
19	44197	Ass'm.—Rotor	43011	Ass'm.—Sp. 5" Longer Anvil (475-476)	
20	30356	Fitting—Grease	43056	Ass'm.—Anvil (477)	
21	44196	Pin—Alignment	43058	Ass'm.—Sp. 3" Longer Anvil (477)	
22	44256	Cylinder	43059	Ass'm.—Sp. 5" Longer Anvil (477)	
23	33958	Plate—Rear End	60	44261	Anvil (472-472B)
24	10203	Bearing—Ball	61	10324	Ball (2) (472-472B)
25	07094	Screw—#10 (4)	62	34455	Retainer—Ball (472-472B)
26	43024	Cap—Housing	63	21414	Spring (472-472B)
27	44139	Cap—Grease	64	34456	Ring—Guide (472-472B)
28	44201	Knob—Output Control	65	21526	Ring—Retainer (472-472B)
29	30257	Pin—Roll	66	30413	Pin (3)
30	10902	Ball	67	10412	Bushing
31	21223	Spring—Tension	*68	30408	Seal
* 32	14291	Ring—"O" (3)	*69	14753	Washer—Fiber
33	43025	Ass'm.—Output Control	70	10299	Ball—Steel (Serial 7001 & up)
* 34	14748	Gasket	71	44199	Insert—Hex. (4)
* 35	14312	Ring—"O"			
* 36	14369	Ring—"O"			
37	43026	Ass'm.—Reversing Valve			
38	33991	Ass'm.—Oiler Screw & Chain			
39	44204	Rack—Reversing Valve			

*These parts included in Tune-Up Set No. 43904

† Includes Fig. 15, 26 thru 34, 38, 40 thru 45, 50 thru 53, 69

SIoux TOOLS Inc.


SIoux CITY, IOWA, U.S.A. 51102

SIoux



TOOLS

Parts List for No's. 475, 476, 477 AIR IMPACT WRENCH and No. 472 & 472B SCREW DRIVER (UP TO SERIAL B99)



Furnish Catalog and Serial Number When Ordering Parts

This pdf incorporates the following model numbers:

475, 476, 477, 472, 472B