



NOTE: Parts are no longer available for this tool.

The manual will continue on the next page.

SIoux**TOOLS**

Parts List for No. 508 and No. 513

HORIZONTAL AIR GRINDER

(Up to Serial B99)

Furnish Catalog, Serial and Model Number When Ordering Parts

Fig- ure	Part No.	Name	Fig- ure	Part No.	Name
1	22636	Spindle—Rotor	36	43228	Handle
2	10531	Plate—Front End	37	44389	Stop
3	12291	Housing (Rear Exhaust)	38	14323	Ring—"O"
	12276	Housing (Front Exhaust)	39	43253	Ass'm.—Crank
4	20367	Plate—Name (508)	40	10902	Ball—Steel
	20375	Plate—Name (513)	41	43232	Ass'm.—Detent Screw & "O" Ring
5	06000	Screw (2)	42	21432	Spring—Detent
6	33997	Vane—Rotor (Set of 4)	43	43664	Valve—Governor (Ser. No. 10,000 & Up)
7	10520	Plate—Rear End	**	33972	Valve—Governor (Up To Ser. No. 9999) (Not Available)
8	10241	Bearing—Ball	**44	10233	Bearing—Ball (Up To Ser. No. 9999) (Not Available)
9	35067	Washer—Wave	45	43666	Ass'm.—Bearing Support & Spindle (Ser. No. 10,000 & Up)
10	43672	Ass'm.—Governor (Ser. No. 10,000 & Up)	**	33966	Ass'y.—Bearing Support & Spindle (Up To Ser. No. 9999) (Not Available)
	43143	Ass'y.—Governor (Up to Ser. 9999) (Also Replaces Fig's. 43 & 44)	46	35069	Weight—Governor (4)
11	14756	Gasket—Motor (Rear Exhaust)	47	44379	Spacer—Governor Weight (4)
	14751	Gasket—Motor (Front Exhaust)	48	30336	Pin—Roll (2)
12	06325	Screw (2)	49	44222	Frame—Governor
13	09704	Washer—Lock (2)	50	21411	Spring—Governor (Red)
14	44245	Retainer—Governor Valve	51	13183	Nut—Governor Adjusting
15	14750	Retainer—Screw (2)	52	44220	Rotor
16	14312	Ring—"O" (2)	53	43022	Ass'm.—Cylinder & Pin
17	34694	Pin—Trigger	54	10243	Bearing—Ball
† 18	53443	Kit—Trigger Conversion (Monetary Lock) (Replaces Fig's. 18, 19 & 26)	55	44219	Key—Rotor
19	35118	Washer	56	44460	Coupling (2)
20	14291	Ring—"O" (2)	57	14033	Pin—Drive (6)
21	09724	Washer—Lock (4)	58	30356	Fitting—Grease
22	07129	Screw (4)	*59	53109	Kit—Spindle Housing (508)
23	14755	Gasket—Inlet		53205	Kit—Spindle Housing (513)
24	35119	Washer	60	22637	Spindle—Tool (508)
25	14372	Valve		22638	Spindle—Tool (513)
26	21413	Spring—Valve	61	10254	Bearing—Ball
27	33993	Screen—Air	62	44459	Nut—Lock (2)
28	1361	Cover—Handle (Rear Exhaust)	63	44462	Flange—Inside (508)
	14063	Cover—Handle (Front Exhaust)		44463	Flange—Inside (513)
	04207	Cover—Hose (Front Exhaust)	64	2312	Guard (508)
29	14275	Protector—Rubber	65	598	Wheel—Grinding (508)
30	06573	Screw (4)	66	44464	Flange—Outside (508)
31	09712	Washer—Lock (4)	67	09622	Nut (508)
32	44388	Cap—Inlet	68	599	Wheel—Grinding (513)
33	14281	Ring—"O"	69	14291	Ring—"O"
34	44434	Rod—Valve			
35	44391	Sleeve—Valve			

*Replaces Figures 58, 59, 62, 63 & 64

**Order Kit No. 43753 (Replaces Figures 43, 44 & 45)

†When Ordering Kit No. 53443 Omit Fig's. 38, 40, 42 & 69 When Re-assembling As Per Instruction On Form No. 674 Furnished With Kit.


SIoux TOOLS INC.
SIoux CITY, IOWA, U.S.A. 51102

SIoux



TOOLS

Parts List for No. 508 and No. 513 HORIZONTAL AIR GRINDER (Up to Serial B99)



Furnish Catalog and Serial Number When Ordering Parts

This pdf incorporates the following model numbers:

508, 513