

NOTE: Parts are no longer available for this tool.


The manual will continue on the next page.



2901 FLOYD BOULEVARD ■ SIOUX CITY, IOWA 51102 ■

## Parts List for Air Impact Wrench No's. 100, 100F, 100E, 100FE

**SERIAL NO'S STARTING WITH "D"** 



## Parts List for Air Impact Wrench No's. 100, 100F, 100E, 100FE

Furnish Catalog, Serial and Model Number When Ordering Parts
SERIAL NO'S STARTING WITH "D"

Fig- ure	Part No.	Name	Fig- ure	Part No.	Name
1.	10247	Bearing - Ball	31.	09712	Washer - Lock #8 (2)*
2.	10538	Plate - Front End	32.	06594	Screw (2)*
3.	54673	Rotor	33.	14785	Gasket
4.	43027	Vane - Rotor (Set of 5)	34.	54648	Driver
<b>5</b> .	54674	Cylinder	35.	54646	Washer - Thrust
6.	10539	Plate - Rear End	36.	65408	Cam
7.	41222	Spring - Rev. Valve Stop	37.	10324	Ball - Steel
8.	44852	Plunger - Rev. Valve Stop	38.	65409	Hammer
9.	10203	Bearing - Ball	39.	54819	Washer (2)*
10.	21459		<b>4</b> 0.	21410	Spring
11.	53941	Housing - (Incl.'s Fig. 20)	41.	54760	Anvil (100)
12.	04220	Ring - ''0'' (2)*	<b>4</b> 2.	43890	Assy - Socket Retainer (100, 100F)
13.	14291	Ring - ''0''	43.	54758	Anvil (100E)
14.	<b>086</b> 49	Screw	44.	53508	Assy - Socket Retainer (100E,
15.	44853	•			100FE)
16.	30613	Pin - Groove	46.	10035	Race - Thrust (3)*
17.	33993	Screen - Air	47.	10070	Bearing - roller
18.	21417	. •	48.	35 <b>2</b> 31	Bail - Front
19.	44100	•	49.	09726	Washer - Lock #10 (4)*
20.	30359	Plug - Pipe	50.	07091	Screw - Soc. Hd. Cap (#10 - 24
21.	14325	Valve			x 3/4( (4)*
22.	53246		51.	53906	Assy Hammer Case (Incl's.
23.	14312	• , ,			Fig.47)
24.	53258	,	52.	40053	Seal
25.	21401	Spring - Valve	53.	14299	Protector - Rubber
26.	21542		54.	1 <b>4</b> 025	Deflector - Air
27.	53182	,	55.	54759	
28.	44754	•	56.	54761	Anvil 3'' Ext. (100F)
29.	53245	Ass'y - Adj. Throttle Valve	57.	54521	Spacer

\*Order Quantity As Needed



This pdf incorporates the following model numbers:

100, 100F, 100E, 100FE