




NOTE: Parts are no longer available for this tool.

The manual will continue on the next page.



PARTS LIST FOR
NO. 1290L AIR SANDER (6000RPM)
NO. 1291L AIR GRINDER (6000RPM)
NO. 1292L AIR POLISHER (3000RPM)
NO. 1296L AIR POLISHER (2000RPM)
(INCLUDES REMOTE EXHAUST)
SERIAL NOS. STARTING WITH "B"



SIoux
TOOLS INC.

250 SNAP-ON DRIVE ■ PO BOX 1596 ■ MURPHY, NC 28906 ■ USA ■

Printed In U.S.A.



PARTS LIST FOR
NO. 1290L AIR SANDER (6000RPM)
NO. 1291L AIR GRINDER (6000RPM)
NO. 1292L AIR POLISHER (3000RPM)
NO. 1296L AIR POLISHER (2000RPM)
(INCLUDES REMOTE EXHAUST)
SERIAL NOS. STARTING WITH "B"

Fig. No.	Part No.	Description
1.	66876	Housing
2.	14171	Handle—Auxiliary
3.	66880	Cover
4.	63575	Stem—Valve
5.	65289	Ring—"O"
6.	21211	Spring
7.	66878	Cap
8.	66963	Screw
9.	35235	Lever—Handle
10.	06099	Screw (2)*
11.	66880A	Cover
12.	30462	Screen
13.	21417	Spring
14.	44100	Bushing—Reducing
15.	43781	Ass'y—Motor (1290L, 1291L)
	43783	Ass'y—Motor (1292L)
	53658	Ass'y—Motor (1296L)
16.	21534	Ring—Retaining
17.	10241	Bearing—Ball
18.	14794	Gasket
19.	13227	Plate—Rear End
20.	44869	Cylinder
21.	43888	Ass'y—Rotor Vanes (Set of 5)
22.	44870	Rotor (1296L)
	54675	Rotor (1292L)
	54676	Rotor (1290L, 1291L)
23.	13226	Plate—Front End (Includes Fig. 24)
24.	10221	Bearing—Ball
25.	41236	Washer—Wave
26.	65831	Ass'y—Planetary Gear (1290L, 1291L)
	63019	Ass'y—Planetary Gear (1292L)
	63011	Ass'y—Planetary Gear (1296L)
27.	10203	Bearing—Ball
28.	25976	Washer
29.	54729	Spindle (1296L)
	54733	Spindle (1292L)
	65825	Spindle (1290L, 1291L)
30.	19206	Gear—Pinion (1290L, 1291L)

Fig. No.	Part No.	Description
31.	30369	Pin—Torrington (1290L, 1291L)(2)*
	30467	Pin—Torrington (1292L, 1296L)(2)*
32.	19324	Ass'y—Gear & Bearing (1292L)(2)*
	19325	Ass'y—Gear & Bearing (1290L, 1291L)(2)*
	19327	Ass'y—Gear & Bearing (1296L)(2)*
33.	10080	Bearing—Needle (1290L, 1291L)(4)*
	10028	Bearing—Needle (1292L, 1296L)(4)*
34.	30356	Fitting—Grease
35.	35260	Washer
36.	21524	Ring—Retainer (1292L, 1296L)
	21753	Ring—Retainer (1290L, 1291L)
37.	54728	Key—Gear Case
38.	19240	Case—Gear
39.	10244	Bearing—Ball
40.	21804	Ring—Retaining
41.	54727	Spacer
42.	04239	Ring—"O"
43.	53525	Ass'y—Air Deflector (Standard Exhaust)
	63166	Ass'y—Remote Exhaust
44.	14339	Ring—"O"
45.	14124	Liner—Air Deflector (Standard Exhaust)
46.	44798	Sleeve—Lock
47.	2336	Guard—7" (1291L)
48.	510	Pad—Backing (1291L)
49.	25894	Washer (1291L)(2)*
50.	512	Nut—Lock (1291L)
51.	30110	Wrench—Allen (1291L)
52.	525	Ass'y—Sanding Disc Holder (1290L)
53.	525-7	Pad—Disc (1290L)
54.	524	Nut—Lock (1290L)
55.	846C	Ass'y—Polishing Disc (1292L, 1296L)
56.	524	Nut—Lock (1292L, 1296L)

Not Shown:
 35320 Wrench

*Order Quantity As Needed

FURNISH CATALOG, SERIAL, AND MODEL NUMBER
 WHEN ORDERING PARTS

SIoux
TOOLS INC.

250 SNAP-ON DRIVE ■ PO BOX 1596 ■ MURPHY, NC 28906 ■ USA ■

Printed In U.S.A.

This pdf incorporates the following model numbers:

1290L, 1291L, 1292L, 1296L