

PERCUSSIVE



PERCUSSIVE ACCESSORIES



Beehive Spring Retainers

Part Number	Description
2207	Chisel Retainer Spring (Use with all except those listed below)
2208	Must use 2208 with 2201B, 2205, 2216, 2217B, and 2219, 2220, 2239, 2244, 2245, 2246, 2247

.401 Parker Taper Shank



270 Rivet Sets

3-1/2" Overall Length

Rivet Head Cupping	Rivet Diameter Size				
	3/32" Part No	1/8" Part No	5/32" Part No	3/16" Part No	1/4" Part No
Button Head	N/A	2229	2230B	2231	2244*
Round Head	2232	2233	2234B	2235	2245*
Brazier Head	2236	2237B	2238	2239	2246*
Universal Head	2240	2241B	2242B	2243B*	2247*

3-1/2" (90 mm) overall length

* Use 2208 Retainer



Hammer Chuck

Part Number	Description	For Use ON
2270	Quick change air hammer chuck	5272A, 5273A, 5274A



Scaling Needles

Part Number	Diameter	Length	Quantity	Used On
2259	0.12"	5"	12	Scalers
2260B	0.12"	5"	19	Scalers
2262	0.12"	7"	19	Scalers



Hammer Accessories

.401 Parker Taper Shank

Part Number	Description	Width		Length	
		in	mm	in	mm
2201B*	Cutter	5/8	16	6	150
2202B	Chisel	5/8	16	6	150
2203	Rivet Buster	5/8	16	5-1/2	140
2204	Expansion Chisel	5/8	16	11	280
2205*	Scraper	1-1/4	30	6	150
2206	Punch			7	175
2210B	Punch			5	127
2212	Spot Weld Breaker			6	150
2213	Splitter			8	200
2214B	Edging Chisel			5	140
2215	Blank Chisel			6	150
2216*	Fork Chisel			6-7/8	175
2217B*	Rust Breaker			5-1/4	135
2218	Bushing Cutter			7	175
2219*	Bushing Driver			4-1/2	115
2220*	Bushing Chisel	1-5/8	40	7	175

* Use 2208 Retainer

